DR. AMBEDKAR COLLEGE, DEEKSHABHOOMI, NAGPUR

Maharashtra Centre for Entrepreneurship Development Cell (Development Programme for Self-Employment).

Guest lecture on (Cartridge Refilling)

Date: 19th October, 2019

Guest Trainer: Mr. Narendra Bhagat (Cartridge Refilling Expert)

The programme was organized by MCED cell, Dr. Ambedkar College, Nagpur on 19th October, 2019 from 10.00 am to 2:00 pm in Room No.1. The trainer Mr. Narendra Bhagat (Cartridge Refilling Expert) explained the procedure Of Laser printer Cartridge Refilling, Ink Jet Printer Cartridge Refilling, Cartridge Repairing, Marketing and Knowledge on waste Management

They told the procedure of Printer Cartridge Refilling as following.....

APPARTUS: - Screw Driver, Nose Plier, Toner Powder, Injection Syringn, Ink Kit And Printer

Procedure:-

❖ REFILL A LASER PRINTER TONER CARTRIDGE

- Remove cartridge from printer.
- Place a newspaper on the surface.
- With the help of screw driver remove the bolts and take off its cover.
- Remove Drum and PCR rod and with the help of pointed screw remove locks and separate it.
- After removing locks clear the dust with the help of Blower Dust.
- Remove a cap from holding tank of toner cartridge.
- Insert toner powder into it and filled it fully, close the cap.
- After that joined the all parts of cartridge.

❖ REFILL AN INJECT PRINTER CARTRIDGE

- Prepare your workplace.
- Turn on the printer, remove back cover over cartridge.
- When the cartridge get in middle remove the ink cartridge.
- Mainly two cartridge are their one is Black and Colors.
- After removing cartridge take off the stickers which is on ink cartridge.
- Fill ink into an Injection Syringn.
- Then after that fill hole slowly through the injection.
- Stop adding ink when a little oozes out of the hole.
- Fill additional colour like Megenta, Cyon, and Yellow.
- Cover the hole with a small piece of tape.
- Reinsert the cartridge into the inject printer.

PREACUTION:-

- ➤ Take care of mouth while refilling the toner powder into the cartridge, don't go in the mouth.
- After inserting ink into the injection syringn, remove air from it.
- > Take care of your clothes while inserting the colors ink into the cartridge;

The session was organized by Dr. Durga Puttewar, Asst. Professor (Coordinator of MCED). All the students were enthusiastically participated in the programme and enjoyed the session. Total 31 Students was presented.













Dr. Durga Puttewar (Co-ordinator)